



## Newline Installation Guide

Newline filters are quickly mounted, and here is a simple guide for an easy installation:

1. Turn off the water supply to the cold outlet, either at the main valve or at a small valve under the sink if available. Locate your cold water outlet and disconnect the cold water hose.
2. The filter can either be mounted on the wall or placed loosely, as it does not need to be upright to function properly.
3. Attach the supplied hoses to each side of the filter housing. Note that there is an inlet and an outlet, marked **IN** and **OUT**.  
The two included hoses are not identical—one fits your cold water outlet, while the other connects the filter housing to the loose hose from your faucet. Once both hoses are attached and tightened to the filter housing, connect the inlet hose to your cold water outlet. Then, connect hose 2 from the filter housing to the loose hose from your faucet, which you previously disconnected from the cold water outlet.
4. Carefully turn the water back on and check for any leaks. If necessary, tighten any connections where leaks occur. Let the water run for **5 minutes** to flush out excess carbon from the filter.